


STINGERChair®




Arm Width Adjustment Knobs

Increase width of seat by extending the arms outward: While seated in chair, lower either hand to the bottom or base of the adjustable arm to locate knob. To unlock arm position, grasp associated knob and turn counter-clockwise to loosen. This will release the locking feature, allowing the arm to move freely inward or outward from seat. Locate desired arm position and turn knob clockwise, locking arm into place.



Lumbar Adjustment Tabs

Adjust the lumbar positioning: While seated in chair, reaching both hands directly behind your back on each side, pinch the small black lumbar tabs on either side of the lumbar region. Simultaneously slide both tabs upward or downward to locate desired lumbar positioning.





Seat Depth Adjustment

Adjust seat depth: While seated in chair, reach forward with right hand, locating rectangular button on lower front corner of seat. Push button inward to release seat depth adjustment. Seat will freely move forward or rearward while button is engaged. Locate desired position and release button to lock.



Seat Height Adjustment


To raise seat height: While seated in chair, lower right hand and take hold of paddle. Lift up on paddle and simultaneously lift your body weight from the chair. The seat will rise. Release paddle when desired seat height position is achieved and seat height will lock into position.

To lower seat height: When seated in chair, lower right hand and take hold of paddle. Lift up on paddle. The seat will lower from your body weight. Release paddle when desired seat height position is achieved and seat height will lock into position.



Reclining Tension Adjustment

Adjust recline tension for different body weights: When seated in chair, lower right hand and grasp the round knob on the lever. Turn forward to increase tilting tension or rearward to loosen tilting tension. Please note: Only 3 x 360° revolutions required to go from minimum to maximum tension. Do not over-turn.



Mesh Back Option

Back Height Adjustment: Locate large square button on lower rear side of mesh back. Push button to engage and back will ratchet up and down. When desired height is achieved, release button and back will lock into position.

Arm Height Adjustment

Engage button under arm pad to release. Arm will move freely up and down. Locate desired position and release button to lock into place.




Arm Pad Fore and Aft Adjustment

Firmly grasp top of arm pad and slide forward or back into desired position.



Arm Pad Pivot Angle Adjustment

Firmly grasp top of arm pad and pivot left or right into desired position.



1) Forward position

Full range of free movement from neutral position, including 3° forward seat pitch: While seated in chair, lower left hand and grasp paddle. Turn the paddle downward through 3 click positions to achieve complete full range of motion.



3) Partially reclined position

Lock chair in partially reclined position: When seated in chair, lower left hand and grasp paddle, turning downward to release; chair will move freely. Lean back into chair, locate the partially reclined position. While holding this position, turn the same paddle fully upward to lock position. To release, turn paddle downward and lean gently back into chair. Chair will once again move freely.



2) Neutral position

Full range of free movement from neutral position:

a) When seated in chair, lean back so chair reclines slightly. Lower left hand and grasp paddle, turning to the middle of the 3 click positions. This will permit full range of motion, eliminating the 3° forward seat pitch.

Lock chair in neutral upright position:

b) When seated in chair, lower left hand and grasp paddle. Turn paddle to the lowest of 3 click positions. This will permit chair to move freely. Lean back slightly and position chair in the neutral position and turn paddle to the highest of the 3 click positions. This will lock chair into the neutral position. To release, turn paddle downward and lean gently back into chair. Chair will once again move freely.

4) Fully reclined position

Lock chair in fully reclined position: When seated in chair, lower left hand and grasp paddle, turning downward to release; chair will move freely. Lean back into chair, locate the fully reclined position. While holding this position, turn the same paddle fully upward to lock position. To release, turn paddle downward and lean gently back into chair. Chair will once again move freely.